




How to USE



*Compatible with wireless charging standard




For fast charge (via cable): connect only one device to power bank to activate fast charge, do not press the power button
For wireless: press the power button once to activate wireless charging, fast charge (via cable) will switch to normal charging mode. After 2 mins of idle, wireless charging will shut off, fast charge will then resume



Please do not charge more than 2 devices at once (wireless charger is included)

Green light indicates wireless charging is activated



Blinking light indicates recharging.
Solid light indicates fully charged.

How to Recharge

