


True Wireless Earbuds AVA+ Y913

USER MANUAL



Please read this manual carefully before using

Guidelines for safe and effective use


1. Do not try to disassemble or replace the product except for the operation methods that are specially marked in the manual. Any parts inside.
2. This product contains a built-in rechargeable battery. It is forbidden to hit, squeeze, puncture, or short-circuit the battery or not replace the battery by yourself. If the battery is incorrectly replaced, there is a danger of an explosion.
3. Do not store the product in extreme temperature (below 0°C or above 45°C). Do not soak the product in water or throw the product into the fire.
4. When charging the charger, please use a charging device with an output voltage of DC 5V/1A. Do not use fast charging electrical appliances, so as not to cause too much battery load, and cause battery damage. Vigorously charging things should not be done.

List of items

- Bluetooth headset x 2
- Charging box x 1
- Charging line x 1
- Instruction x 1
- Ear cap x 2



Product view




1. LED Indicator
2. Touch Area
3. Earphones Charging Contacts
4. USB-C Charging Port
5. Charging Case LED

Power ON/OFF

- 1. Power on**
Method 1: Open the charging case, take out the earbuds, they will power on automatically.
Method 2: Long press left and right earbuds about seconds, the earbuds will power
- 2. Power off**
Method 1: Put the earbuds into the charging case, the earbuds will power off automatically.
Method 2: Long press left and right earbuds for 5 seconds the earbuds will power off.
- Remark: Earbuds power off when they stay out of range for over 5 minutes.

Pairing

1. When using Y913 true wireless earphone, the first time. Take the earbuds. The master earphone indicator will blink blue alternately.
2. Turn on Bluetooth on your device.
3. Search and select "AVA+ Y913".
4. When connected, the indicators light off.



Multi Functions

- 1. Play music**
Previous song: triple tap on the left earphone.
Next song: triple tap on the right earphone.
Volume increase: long press the left earphone for 1.5 seconds to increase the volume by one level.
Volume reduction: long press the right earphone for 1.5 seconds to reduce the volume by one level.
Pause/play: single tap on the left/right earphones.
- 2. Hands free telephone (paired operation of two earphones)**
Answer/End the call: single tap on the left/right earphones.
Refuse to answer a call: Press and hold the left/right earphones for one second.
- 3. Activate voice assistant**
Activate voice assistant: after the headset is successfully connected with the mobile phone, double tap on the left/right to activate the voice assistant.

LED Indications

- Earphone power on:** the left/right earphone indicator light is always blue.
Earphone power off: the left/right earphone indicator light is blue flash 3 times and then go out.
Pairing mode: the left earphone indicator is flashing blue and the right earphone indicator is off.
Bluetooth pairing successful: left/right earphone indicator is off.
Charging the earphone in charging case: while charging the earphone in charging case, the earphone indicator light is always blue; When fully charged, the earphone light goes out.
Charging of charging case: during the charging process, the white light of charging case flashes, and the white light is always on when it is fully charged.

Product specifications

- Effective distance: ≥10m
 - Impedance: 32Ω
 - Microphone sensitivity: -40dB±3dB
 - Frequency response: 20Hz-20KHz
 - Playtime: about 4 hours
 - Earbuds battery capacity: 30mAh*2
 - Battery capacity of charging case: 250mAh
 - Earbuds charging time: about 1 hours.
 - Charging time of charging case: about 1.5 hours
- (All technical data is subject to actual performance)


Warning

1. Listening to earbuds at high volume levels, particularly over extended periods of time, may damage your hearing.
2. Supervise children when using equipment, product is not a toy.
3. The small parts included with this product can be a choking hazard. This product is not intended for use by small children and should be kept away from children under 3 years of age.



Tai nghe không dây AVA+ Y913

HƯỚNG DẪN SỬ DỤNG



Vui lòng đọc kỹ hướng dẫn sử dụng trước khi dùng.

Hướng dẫn sử dụng an toàn và hiệu quả


1. Không cố gắng tháo rời hoặc thay thế bất kỳ bộ phận nào bên trong.
2. Sản phẩm có pin sạc tích hợp. Không làm rơi hoặc va đập sản phẩm trên bề mặt cứng hoặc làm chập mạch pin, không tự ý thay pin.
3. Không bảo quản sản phẩm ở nhiệt độ quá cao (dưới 0°C hoặc trên 45°C). Không ngâm sản phẩm trong nước hoặc ngâm vào lửa.
4. Khi sạc pin cho sản phẩm vui lòng dùng bộ sạc có đầu ra 5V/1A. Không dùng các thiết bị sạc nhanh để sạc cho sản phẩm. Thời gian sạc liên tục không được vượt quá thời gian sạc được chỉ định.

Bộ sản phẩm gồm

- Tai nghe Bluetooth x 2
- Hộp sạc x 1
- Cáp sạc x 1
- Hướng dẫn sử dụng x 1
- Đệm tai thay thế x 2



Tổng quan sản phẩm




1. Đèn LED tai nghe
2. Khu vực cảm ứng
3. Điểm tiếp xúc sạc tai nghe
4. Cổng sạc USB-C
5. Đèn LED hộp sạc

Bật/Tắt nguồn

- 1. Bật nguồn**
Cách 1: Mở hộp sạc, lấy 2 tai nghe ra khỏi hộp sạc, tai nghe sẽ tự động bật nguồn.
Cách 2: Nhấn và giữ tai nghe bên trái và bên phải trong vài giây, tai nghe sẽ bật nguồn.
- 2. Tắt nguồn**
Cách 1: Đặt 2 tai nghe vào hộp sạc, tai nghe sẽ tự động tắt nguồn.
Cách 2: Nhấn và giữ tai nghe bên trái và bên phải trong 5 giây, tai nghe sẽ tắt nguồn.
- Lưu ý: Tai nghe sẽ tắt nguồn khi nằm ngoài phạm vi Bluetooth trong hơn 5 phút.

Kết nối

1. Khi lần đầu sử dụng tai nghe TWS Y913, lấy 2 tai nghe ra khỏi hộp sạc, đèn báo của tai nghe chính sẽ nhấp nháy màu xanh.
2. Bật Bluetooth trên thiết bị của bạn.
3. Tìm kiếm và chọn "AVA+ Y913".
4. Khi được kết nối thành công, đèn báo trên tai nghe sẽ tắt.



Đa chức năng

- 1. Nghe nhạc**
Bài hát tiếp theo: chạm 3 lần trên tai nghe bên phải.
Bài hát trước đó: chạm 5 lần trên tai nghe bên trái.
Tăng âm lượng: chạm và giữ khoảng 1.5 giây trên tai nghe bên trái để tăng âm lượng lên 1 mức.
Giảm âm lượng: chạm và giữ khoảng 1.5 giây trên tai nghe bên phải để giảm âm lượng xuống 1 mức.
Đang/Phát nhạc: chạm 1 lần trên tai nghe trái hoặc phải.
Trả lời/Kết thúc cuộc gọi: chạm 1 lần trên tai nghe trái hoặc phải.
Từ chối cuộc gọi: chạm và giữ khoảng 1 giây trên tai nghe bên trái hoặc phải.
- 3. Try lý giọng nói**
Kích hoạt trợ lý giọng nói: sau khi tai nghe kết nối thành công với thiết bị, chạm 2 lần trên tai nghe bên trái hoặc phải.

Trạng thái đèn LED

- Bật nguồn tai nghe:** Đèn báo trên tai/trái/phải sáng màu xanh.
Tắt nguồn tai nghe: Đèn báo trên tai nghe trái/phải nhấp nháy màu xanh 3 lần rồi tắt.
Chế độ chờ ghép nối: Đèn báo trên tai nghe bên trái nhấp nháy màu xanh, đèn báo tai nghe bên phải tắt.
Ghép nối thành công: Đèn báo của hai tai nghe sẽ tắt.
Sạc tai nghe-đang sạc: Đèn báo của hai tai nghe sẽ nhấp nháy màu xanh.
Sạc tai nghe-đã sạc đầy: Đèn báo của hai tai nghe sẽ nhấp nháy màu trắng.
Sạc hộp sạc: Khi hộp sạc được sạc, đèn báo sẽ nhấp nháy màu trắng; Khi được sạc đầy, đèn trắng sẽ sáng ổn định.

Thông số kỹ thuật

- Khoảng cách kết nối: ≥10m
 - Trở kháng: 32Ω
 - Độ nhạy micrô: -40dB±3dB
 - Tần số: 20Hz-20KHz
 - Thời gian sử dụng: khoảng 4 giờ
 - Dung lượng pin tai nghe: 30mAh*2
 - Dung lượng pin hộp sạc: 250mAh
 - Thời gian sạc tai nghe: khoảng 1 giờ
 - Thời gian sạc hộp sạc: khoảng 1.5 giờ
- (Tất cả thông số kỹ thuật tùy thuộc vào hiệu suất sử dụng thực tế)

Cảnh báo

1. Không nên nghe tai nghe ở mức âm lượng lớn trong thời gian dài, vì có thể làm hỏng thính giác của bạn.
2. Giám sát trẻ em khi sử dụng thiết bị. Các bộ phận nhỏ có thể trở thành vật cản gây nguy hiểm cho trẻ.
3. Sản phẩm này không dành cho trẻ nhỏ và trẻ em dưới 3 tuổi.

