

User Manual



Wired Earbuds

Model NO.: E2

Thank you for purchasing your new AVA+ E2 Wired Earbuds.

We recommend that you spend some time reading this instruction manual in order to fully understand all the operational features it offers.

Read all the safety instructions carefully before use and keep this instruction manual for future reference.

Safety Rules


1. Do not store the product in extreme temperature (below 0 C or above 45 C)
2. Do not use chemicals or detergents to clean the product.
3. Do not drop or knock the product on hard surfaces.
4. Do not scrape the surface of product with sharp objects.
5. Do not try to take the product apart.

In the Box

USB-C Earbuds
User manual
Ear-Tips x 3 (S/M/L)

-1-

Overview



-2-

Specification

Speaker driver	10 mm
Impedance	32Ω
Frequency response	100Hz - 20kHz
Cable length	1.2m
Connector	Type-C
Weight	13.2g

Multi Functions

Function	Buttom
Play/Pause	Single Press
Volume up	Slide from bottom to top
Volume down	Slide from top to bottom
Answer a call	Single Press(Call coming)
End a call (This control depends on the phone UI)	Single Press for iPhone type-C port (During call) Long Press 2S for Android series (During call)
Reject a call	Long Press 2s(Call coming)
Mute a call (This control depends on the phone UI)	Long Press 2S for iPhone type-C port (During call) Single Press for Android series (During call)

-3-

WARNING

1. Listening to earbuds at high volume levels, particularly over extended periods of time, may damage your hearing.
2. Supervise children when using equipment. This product is not a toy.
3. The small parts included with this product can be a choking hazard. This product is not intended for use by small children and should be kept away from children under 3 years of age.



-4-

Hướng dẫn sử dụng



Tai nghe dây

Model NO.: E2

Đọc tất cả hướng dẫn sử dụng an toàn trước khi sử dụng

Quy tắc an toàn


1. Không bảo quản sản phẩm ở nhiệt độ quá cao (dưới 0 C hoặc trên 45 C)
2. Không sử dụng hóa chất, chất tẩy rửa để vệ sinh sản phẩm.
3. Không làm rơi hoặc va đập sản phẩm trên bề mặt cứng.
4. Không cạo bề mặt sản phẩm bằng các vật sắc nhọn.
5. Không cố tháo rời sản phẩm.

Bên trong hộp

Tai nghe dây jack Type-C
Hướng dẫn sử dụng
Đệm tai thay thế x 3 (S/M/L)

-1-

Tổng quan sản phẩm



-2-

Thông số kỹ thuật

Màng loa	10 mm
Điện trở	32Ω
Tần số	100Hz - 20kHz
Độ dài dây	1.2m
Cổng kết nối âm thanh	Kết nối qua Jack Type-C
Trọng lượng	13.2 gram

Đa chức năng

Chức năng	Thao tác
Phát/Dừng nhạc	Nhấn 1 lần
Tăng âm lượng	Trượt nút điều chỉnh âm lượng từ dưới lên
Giảm âm lượng	Trượt nút điều chỉnh âm lượng từ trên xuống
Trả lời cuộc gọi	Nhấn 1 lần khi có cuộc gọi đến
Kết thúc cuộc gọi (Điều khiển này phụ thuộc vào tùy dồng điện thoại)	Đối với điện thoại iPhone: Nhấn 1 lần khi đang trong cuộc gọi Đối với điện thoại Android: nhấn và giữ 2 giây khi đang trong cuộc gọi
Từ chối cuộc gọi	Nhấn và giữ khoảng 2 giây khi có cuộc gọi đến
Tắt tiếng cuộc gọi (Điều khiển này phụ thuộc vào tùy dồng điện thoại)	Đối với điện thoại iPhone: nhấn và giữ 2 giây khi đang trong cuộc gọi Đối với điện thoại Android: Nhấn 1 lần khi đang trong cuộc gọi

-3-

Cảnh báo

1. Không nên nghe tai nghe ở mức âm lượng lớn trong thời gian dài, vì có thể làm hỏng thính giác của bạn.
2. Giám sát trẻ em khi sử dụng thiết bị. Các bộ phận nhỏ đi kèm với sản phẩm này có thể gây nguy cơ nghẹt thở. Sản phẩm này không dành cho trẻ nhỏ sử dụng và để xa tầm tay trẻ em dưới 3 tuổi.



-4-