


正面

True Wireless Earphone
Model NO.: RZ09



Thank you for purchasing your new RZ09 true wireless earphone.

We recommend that you spend some time reading this instruction manual in order to fully understand all the operational features it offers.

Read all the safety instructions carefully before use and keep this instruction manual for future reference.

1. Charge the earbuds and the charging case at least once every 6 months.
2. Do not store the product in extreme temperature (below 0 °C or above 45 °C)
3. Do not use chemicals or detergents to clean the product.
4. Do not drop or knock the product on hard surfaces.
5. Do not scrape the surface of product with sharp objects.
6. Do not try to take the product apart.

Wireless Earbuds
Type-C Charging Cable
User manual
Ear tip

The diagram illustrates the touch area and charging contacts for the Earphones Charging Case. It shows two earphones with dashed lines indicating the 'Touch Area' and 'Earphones Charging Contacts'. Below, a side view of the case shows the 'USB-C Charging Port' and a top view shows the 'Charging Case LED'.

Bluetooth version	V5.4
BT profiles support	HFP/ HSP/ A2DP/ AVRCP
Bluetooth range	≤10m
Frequency response	2.402GHz-2.480GHz
Battery capacity	35mAh for each earbud 350mAh for charging case
Charging time	Around 2 hours
Playing time	About 4 hours
Speaker Driver	10mm

Power ON
Open the charging case, take out the earbuds, they will power on automatically.

Put the earbuds into the charging case, the earbuds will power off automatically.
Remark: Earbuds power off when they stay out of range for about 3 minutes.

1. Fully charge both the earbuds and the charging case before the first use.
2. To prevent damage, use the provided USB-C cable.
3. Fully dry off the charging port and the USB port before charging.
4. Charging takes around 2 hours.

Device	Status	LED indicator
Charging Case (red)	Charging	The red light flashes
	Fully charged	The red light is on


1. When using Rezo RZ09 true wireless earphone, the first time. Take the earbuds.
2. Turn on Bluetooth on your device.
3. Search and select "Rezo RZ09".

Function	Left earbud	Right earbud
Play/Pause Answer/End a call	Single tap either side	
Next song		Double tap
Previous song	Double tap	
Volume up		Triple tap
Volume down	Triple tap	
Mode switch	when turn on, long press 3 seconds on either side (Transparent mode/ANC on/normal mode cyclic switching)	
Reject a call	True Wireless Earphone	
Active Siri/Google Assistant	Four tap on either side to launch	
Reset	When the device is powered on and not connected to Bluetooth, quickly click 5 times	

1. Listening to earbuds at high volume levels, particularly over extended periods of time, may damage your hearing.
2. Supervise children when using equipment. This product is not a toy.
3. The small parts included with this product can be a choking hazard. This product is not intended for use by small children and should be kept away from children under 3 years of age.



Tai nghe không dây
Model No. : RZ09



Đọc tất cả hướng dẫn sử dụng an toàn trước khi sử dụng

1. Sạc tai nghe và hộp sạc ít nhất 6 tháng một lần.
2. Không bảo quản sản phẩm ở nhiệt độ quá cao (dưới 0°C hoặc trên 45°C).
3. Không sử dụng hóa chất, chất tẩy rửa để vệ sinh sản phẩm.
4. Không làm rơi hoặc va đập sản phẩm trên bề mặt cứng.
5. Không cạo bề mặt sản phẩm bằng các vật sắc nhọn.
6. Không cho tháo rời sản phẩm.

Tai nghe không dây
Cáp sạc Type-C
Hướng dẫn sử dụng
Đệm tai thay thế

Vùng cảm ứng

Điểm tiếp xúc sạc tại nghe

Cổng sạc USB-C

Đèn LED hộp sạc

Phiên bản Bluetooth	V5.4
Cấu hình Bluetooth	HFP/ HSP/ A2DP/ AVRCP
Phạm vi Bluetooth	≤10m
Tần số	2.402GHz-2.480GHz
Dung lượng pin	Tai nghe: 35mAh*2 Hộp sạc: 350mAh
Thời gian sạc	Khoảng 2 giờ
Thời gian sử dụng	Khoảng 4 giờ
Màng loa	10mm

Bật nguồn
Mở hộp sạc, lấy 2 tai nghe ra, tai nghe sẽ tự động bật nguồn.

Tắt nguồn
Đặt 2 tai nghe vào hộp sạc, tai nghe sẽ tự động tắt nguồn.
Lưu ý: Tai nghe sẽ tắt nguồn khi nằm ngoài phạm vi Bluetooth trong hơn 3 phút.

1. Sạc đầy cả tai nghe và hộp sạc trước lần sử dụng đầu tiên.
2. Để tránh hư hỏng, hãy sử dụng cáp USB-C đi kèm
3. Lau khô hoàn toàn điểm tiếp xúc sạc của tai nghe và cổng sạc của hộp sạc trước khi sạc.
4. Quá trình sạc mất khoảng 2 giờ.

Thiết bị	Trạng thái	Đèn báo
Hộp sạc (Đèn đỏ)	Đang sạc	Đèn đỏ sáng nhấp nháy
	Sạc đầy	Đèn đỏ sáng ổn định

1. Khi lần đầu sử dụng tai nghe Rezo RZ09. Lấy 2 tai nghe ra khỏi hộp sạc.
2. Bật Bluetooth trên thiết bị của bạn.
3. Tìm kiếm và chọn "Rezo RZ09".

Chức năng	Tai nghe bên trái	Tai nghe bên phải
Chơi/dùng nhạc	Chạm 1 lần	
Trả lời/Kết thúc cuộc gọi		
Bài hát tiếp theo		Chạm 2 lần
Bài hát trước đó	Chạm 2 lần	
Tăng âm lượng		Chạm 3 lần
Giảm âm lượng	Chạm 3 lần	
Chuyển chế độ	Khi tai nghe bật, chạm và giữ 3 giây để chuyển đổi giữa chế độ xuyên âm/ANC/Bình thường	
Từ chối cuộc gọi	Chạm và giữ	
Trợ lý ảo	Chạm 4 lần	
Cài đặt gốc	Khi tai nghe được bật và không kết nối với bất cứ thiết bị nào, chạm 5 lần	

1. Không nên nghe tai nghe ở mức âm lượng lớn trong thời gian dài, vì có thể làm hỏng thính giác của bạn.
2. Giám sát trẻ em khi sử dụng thiết bị. Các bộ phận nhỏ đi kèm với sản phẩm này có thể gây nguy cơ nghẹt thở. Sản phẩm này không dành cho trẻ nhỏ sử dụng và để xa tầm tay trẻ em dưới 3 tuổi.



背面