







User Manual  True Wireless Earphone Model No.: P310	Thank you for purchasing your new P310 true wireless earphone. We recommend that you spend some time reading this instruction manual in order to fully understand all the operational features it offers. Read all the safety instructions carefully before use and keep this instruction manual for future reference. Safety Rules - Charge the earbuds and the charging case at least once every 6 months. - Do not store the product in extreme temperature (below 0℃ or above 45℃) - Do not use chemicals or detergents to clean the product. - Do not drop or knock the product on hard surfaces. - Do not scrape the surface of product with sharp objects. - Do not try to take the product apart. In the Box Wireless Earbuds Type-C Charging Cable User manual -1-	Product Overview  1. LED Indicator 2. Touch Area 3. Earphones Charging Contacts 4. Microphone 5. USB-C Charging Port 6. Charging Case LED -2-	Specification <table><tr><td>Bluetooth version</td><td>V5.4</td></tr><tr><td>BT profiles support</td><td>HSP, HFP, A2DP, AVRCP</td></tr><tr><td>Bluetooth range</td><td>10 m / 33 ft</td></tr><tr><td>Frequency response</td><td>20 Hz - 20 kHz</td></tr><tr><td>Battery capacity</td><td>30mAh for each earbuds 300mAh for charging case</td></tr><tr><td>Charging time</td><td>Around 1.5 hours</td></tr><tr><td>Playing time</td><td>5-7hours</td></tr><tr><td>Speaker Driver</td><td>φ13mm</td></tr><tr><td>Earbuds weight</td><td>3.4g each</td></tr><tr><td>Case weight</td><td>23.4g</td></tr></table> Power ON/OFF Power ON 1. Open the charging case, take out the earbuds, they will power on automatically. 2. Long press left and right earbuds for 3 seconds, the earbuds will power on. -3-	Bluetooth version	V5.4	BT profiles support	HSP, HFP, A2DP, AVRCP	Bluetooth range	10 m / 33 ft	Frequency response	20 Hz - 20 kHz	Battery capacity	30mAh for each earbuds 300mAh for charging case	Charging time	Around 1.5 hours	Playing time	5-7hours	Speaker Driver	φ13mm	Earbuds weight	3.4g each	Case weight	23.4g	Charging Power OFF - Put the earbuds into the charging case, the earbuds will power off automatically. - Long press left and right earbuds for 5 seconds, the earbuds will power off Remark: Earbuds power off when they star out of range for over 5 minutes. Charging - Fully charge both the earbuds and the charging case before the first use. - To prevent damage, use the provided USB cable. - Fully dry off the charging port and the USB port before charging. - Charging takes around 1.5 hours. -4-	LED Indications <table><tr><th>Device</th><th>Status</th><th>LED indicator</th></tr><tr><td rowspan="4">Earbuds (White & Green)</td><td>Charging</td><td>White Lights on</td></tr><tr><td>Fully Charged</td><td>The white light turns green and off after 30 seconds</td></tr><tr><td>Pairing mode</td><td>Master: White and green light flashing alternately Slave: Green light flashes every 5 seconds</td></tr><tr><td>Connected</td><td>Lights off</td></tr><tr><td rowspan="3">Charging Case (White & Green)</td><td>Charging</td><td>White light flashing</td></tr><tr><td>Fully charged</td><td>White light on</td></tr><tr><td>Low battery</td><td>Green flash slowly</td></tr><tr><td>Reset</td><td>When the earbuds disconnected with device, power-on state</td><td>White and green lights are on at the same time and then the white light blinks 1s to power off</td></tr></table> -5-	Device	Status	LED indicator	Earbuds (White & Green)	Charging	White Lights on	Fully Charged	The white light turns green and off after 30 seconds	Pairing mode	Master: White and green light flashing alternately Slave: Green light flashes every 5 seconds	Connected	Lights off	Charging Case (White & Green)	Charging	White light flashing	Fully charged	White light on	Low battery	Green flash slowly	Reset	When the earbuds disconnected with device, power-on state	White and green lights are on at the same time and then the white light blinks 1s to power off	Pairing - When using P310 true wireless earphone, the first time. Take out the earbuds, the master earbud white and green light flashing alternately, slave earbud green light flashes every 5 seconds. - Turn on Bluetooth on your device. - Search and select "AVA+ P310". - When connected, the indicators light off  -6-	Multi Functions <table><tr><th>Function</th><th>Left earbud</th><th>Right earbud</th></tr><tr><td>Play/Pause Answer a Call</td><td>Single tap</td><td>Single tap</td></tr><tr><td>Next song</td><td></td><td>Double tap</td></tr><tr><td>Previous song</td><td>Double tap</td><td></td></tr><tr><td>Volume up</td><td></td><td>Long touch for 2s</td></tr><tr><td>Volume down</td><td>Long touch for 2s</td><td></td></tr><tr><td>Game mode</td><td>Triple tap</td><td></td></tr><tr><td>End a call</td><td>Double tap</td><td>Double tap</td></tr><tr><td>Reject a call</td><td>Long touch for 2s</td><td>Long touch for 2s</td></tr><tr><td>Active Siri/ Google Assistant</td><td></td><td>Triple tap</td></tr><tr><td>Reset</td><td colspan="2">When the device is not connected, Tap 5 times quickly</td></tr></table> -7-	Function	Left earbud	Right earbud	Play/Pause Answer a Call	Single tap	Single tap	Next song		Double tap	Previous song	Double tap		Volume up		Long touch for 2s	Volume down	Long touch for 2s		Game mode	Triple tap		End a call	Double tap	Double tap	Reject a call	Long touch for 2s	Long touch for 2s	Active Siri/ Google Assistant		Triple tap	Reset	When the device is not connected, Tap 5 times quickly		WARNING - Listening to earbuds at high volume levels, particularly over extended periods of time, may damage your hearing. - Supervise children when using equipment. product is not a toy. - The small parts included with this product can be a choking hazard. This product is not intended for use by small children and should be kept away from children under 3 years of age.  MADE IN CHINA -8-
Bluetooth version	V5.4																																																																																		
BT profiles support	HSP, HFP, A2DP, AVRCP																																																																																		
Bluetooth range	10 m / 33 ft																																																																																		
Frequency response	20 Hz - 20 kHz																																																																																		
Battery capacity	30mAh for each earbuds 300mAh for charging case																																																																																		
Charging time	Around 1.5 hours																																																																																		
Playing time	5-7hours																																																																																		
Speaker Driver	φ13mm																																																																																		
Earbuds weight	3.4g each																																																																																		
Case weight	23.4g																																																																																		
Device	Status	LED indicator																																																																																	
Earbuds (White & Green)	Charging	White Lights on																																																																																	
	Fully Charged	The white light turns green and off after 30 seconds																																																																																	
	Pairing mode	Master: White and green light flashing alternately Slave: Green light flashes every 5 seconds																																																																																	
	Connected	Lights off																																																																																	
Charging Case (White & Green)	Charging	White light flashing																																																																																	
	Fully charged	White light on																																																																																	
	Low battery	Green flash slowly																																																																																	
Reset	When the earbuds disconnected with device, power-on state	White and green lights are on at the same time and then the white light blinks 1s to power off																																																																																	
Function	Left earbud	Right earbud																																																																																	
Play/Pause Answer a Call	Single tap	Single tap																																																																																	
Next song		Double tap																																																																																	
Previous song	Double tap																																																																																		
Volume up		Long touch for 2s																																																																																	
Volume down	Long touch for 2s																																																																																		
Game mode	Triple tap																																																																																		
End a call	Double tap	Double tap																																																																																	
Reject a call	Long touch for 2s	Long touch for 2s																																																																																	
Active Siri/ Google Assistant		Triple tap																																																																																	
Reset	When the device is not connected, Tap 5 times quickly																																																																																		
Hướng dẫn sử dụng  Tai nghe không dây Model No.: P310	Đọc tất cả hướng dẫn sử dụng an toàn trước khi sử dụng. Quy tắc an toàn - Sạc tai nghe và hộp sạc ít nhất 6 tháng một lần. - Không bảo quản sản phẩm ở nhiệt độ quá cao (dưới 0℃ hoặc trên 45℃) . - Không sử dụng hóa chất, chất tẩy rửa để vệ sinh sản phẩm. - Không làm rơi hoặc va đập sản phẩm trên bề mặt cứng. - Không cào bề mặt sản phẩm bằng các vật sắc nhọn. - Không cố tháo rời sản phẩm. Bên trong hộp Tai nghe không dây Cáp sạc Type-C Hướng dẫn sử dụng -1-	Tổng quan sản phẩm  1. Đèn LED tai nghe 2. Vùng cảm ứng 3. Điểm tiếp xúc sạc tai nghe 4. Micro 5. Cổng sạc USB-C 6. Đèn LED hộp sạc -2-	Thông số kỹ thuật <table><tr><td>Phiên bản Bluetooth</td><td>V5.4</td></tr><tr><td>Cấu hình Bluetooth</td><td>HSP, HFP, A2DP, AVRCP</td></tr><tr><td>Phạm vi Bluetooth</td><td>10 m / 33 ft</td></tr><tr><td>Tần số</td><td>20 Hz - 20 kHz</td></tr><tr><td>Dung lượng pin</td><td>Tai nghe: 30mAh*2 Hộp sạc: 300mAh</td></tr><tr><td>Thời gian sạc</td><td>Khoảng 1.5 giờ</td></tr><tr><td>Thời gian sử dụng</td><td>Khoảng 5-7 giờ</td></tr><tr><td>Màng loa</td><td>φ13mm</td></tr><tr><td>Trọng lượng tai nghe</td><td>3.4g*2</td></tr><tr><td>Trọng lượng hộp sạc</td><td>23.4g</td></tr></table> Bật/Tắt nguồn Bật nguồn 1. Mở hộp sạc, lấy 2 tai nghe ra, tai nghe sẽ tự động bật nguồn. 2. Nhấn và giữ tai nghe bên trái và bên phải trong 3 giây, tai nghe sẽ bật nguồn. -3-	Phiên bản Bluetooth	V5.4	Cấu hình Bluetooth	HSP, HFP, A2DP, AVRCP	Phạm vi Bluetooth	10 m / 33 ft	Tần số	20 Hz - 20 kHz	Dung lượng pin	Tai nghe: 30mAh*2 Hộp sạc: 300mAh	Thời gian sạc	Khoảng 1.5 giờ	Thời gian sử dụng	Khoảng 5-7 giờ	Màng loa	φ13mm	Trọng lượng tai nghe	3.4g*2	Trọng lượng hộp sạc	23.4g	Tắt nguồn - Đặt 2 tai nghe vào hộp sạc, tai nghe sẽ tự động tắt nguồn. - Nhấn và giữ tai nghe bên trái và bên phải trong 5 giây, tai nghe sẽ tắt nguồn. Lưu ý: Tai nghe sẽ tắt nguồn khi nằm ngoài phạm vi Bluetooth trong hơn 5 phút. Sạc pin - Sạc đầy cả tai nghe và hộp sạc trước lần sử dụng đầu tiên. - Để tránh hư hỏng, hãy sử dụng cáp USB-C đi kèm. - Lau khô hoàn toàn điểm tiếp xúc sạc của tai nghe và cổng sạc của hộp sạc trước khi sạc. - Quá trình sạc mất khoảng 1.5 giờ. -4-	Trạng thái đèn LED <table><tr><th>Thiết bị</th><th>Trạng thái</th><th>Đèn báo</th></tr><tr><td rowspan="4">Tai nghe (Đèn trắng và xanh)</td><td>Đang sạc</td><td>Đèn trắng sáng ổn định</td></tr><tr><td>Sạc đầy</td><td>Đèn trắng chuyển sang màu xanh và tắt sau 30 giây</td></tr><tr><td>Chế độ ghép nối</td><td>Tai chính: Đèn trắng và đèn xanh nhấp nháy luân phiên Tai phụ: Đèn xanh nhấp nháy 5 giây mỗi lần</td></tr><tr><td>Kết nối thành công</td><td>Đèn tắt</td></tr><tr><td rowspan="3">Hộp sạc (Đèn trắng và xanh)</td><td>Đang sạc</td><td>Đèn trắng sáng nhấp nháy</td></tr><tr><td>Sạc đầy</td><td>Đèn trắng sáng ổn định</td></tr><tr><td>Pin yếu</td><td>Đèn xanh nhấp nháy chậm</td></tr><tr><td>Cài đặt gốc</td><td>Khi tai nghe ngắt kết nối với thiết bị, trạng thái bật nguồn</td><td>Đèn trắng và xanh sáng cùng lúc sau đó đèn trắng nhấp nháy 1 giây để tắt nguồn</td></tr></table> -5-	Thiết bị	Trạng thái	Đèn báo	Tai nghe (Đèn trắng và xanh)	Đang sạc	Đèn trắng sáng ổn định	Sạc đầy	Đèn trắng chuyển sang màu xanh và tắt sau 30 giây	Chế độ ghép nối	Tai chính: Đèn trắng và đèn xanh nhấp nháy luân phiên Tai phụ: Đèn xanh nhấp nháy 5 giây mỗi lần	Kết nối thành công	Đèn tắt	Hộp sạc (Đèn trắng và xanh)	Đang sạc	Đèn trắng sáng nhấp nháy	Sạc đầy	Đèn trắng sáng ổn định	Pin yếu	Đèn xanh nhấp nháy chậm	Cài đặt gốc	Khi tai nghe ngắt kết nối với thiết bị, trạng thái bật nguồn	Đèn trắng và xanh sáng cùng lúc sau đó đèn trắng nhấp nháy 1 giây để tắt nguồn	Kết nối - Khi lần đầu sử dụng tai nghe TWS P310. Lấy 2 tai nghe ra khỏi hộp sạc, đèn báo của tai nghe chính sẽ nhấp nháy màu xanh và trắng, đèn báo tai nghe phụ sẽ nhấp nháy màu xanh 5 giây mỗi lần. - Bật Bluetooth trên thiết bị của bạn. - Tìm kiếm và chọn "AVA+ P310". - Khi được kết nối thành công, đèn báo trên tai nghe sẽ tắt.  -6-	Đa chức năng <table><tr><th>Chức năng</th><th>Tai nghe bên trái</th><th>Tai nghe bên phải</th></tr><tr><td>Chơi/dừng nhạc Trả lời cuộc gọi</td><td>Chạm 1 lần</td><td>Chạm 1 lần</td></tr><tr><td>Bài hát tiếp theo</td><td></td><td>Chạm 2 lần</td></tr><tr><td>Bài hát trước đó</td><td>Chạm 2 lần</td><td></td></tr><tr><td>Tăng âm lượng</td><td></td><td>Chạm và giữ 2 giây</td></tr><tr><td>Giảm âm lượng</td><td>Chạm và giữ 2 giây</td><td></td></tr><tr><td>Chế độ chơi game</td><td>Chạm 3 lần</td><td></td></tr><tr><td>Kết thúc cuộc gọi</td><td>Chạm 2 lần</td><td>Chạm 2 lần</td></tr><tr><td>Từ chối cuộc gọi</td><td>Chạm và giữ 2 giây</td><td>Chạm và giữ 2 giây</td></tr><tr><td>Trợ lý ảo</td><td></td><td>Chạm 3 lần</td></tr><tr><td>Cài đặt gốc</td><td colspan="2">Ngắt kết nối với mọi thiết bị, chạm 5 lần</td></tr></table> -7-	Chức năng	Tai nghe bên trái	Tai nghe bên phải	Chơi/dừng nhạc Trả lời cuộc gọi	Chạm 1 lần	Chạm 1 lần	Bài hát tiếp theo		Chạm 2 lần	Bài hát trước đó	Chạm 2 lần		Tăng âm lượng		Chạm và giữ 2 giây	Giảm âm lượng	Chạm và giữ 2 giây		Chế độ chơi game	Chạm 3 lần		Kết thúc cuộc gọi	Chạm 2 lần	Chạm 2 lần	Từ chối cuộc gọi	Chạm và giữ 2 giây	Chạm và giữ 2 giây	Trợ lý ảo		Chạm 3 lần	Cài đặt gốc	Ngắt kết nối với mọi thiết bị, chạm 5 lần		Cảnh báo - Không nên nghe tai nghe ở mức âm lượng lớn trong thời gian dài, vì có thể làm hỏng thính giác của bạn. - Giám sát trẻ em khi sử dụng thiết bị. Các bộ phận nhỏ đi kèm với sản phẩm này có thể gây nguy cơ nghẹt thở. Sản phẩm này không dành cho trẻ nhỏ sử dụng và để xa tầm tay trẻ em dưới 3 tuổi.  MADE IN CHINA -8-
Phiên bản Bluetooth	V5.4																																																																																		
Cấu hình Bluetooth	HSP, HFP, A2DP, AVRCP																																																																																		
Phạm vi Bluetooth	10 m / 33 ft																																																																																		
Tần số	20 Hz - 20 kHz																																																																																		
Dung lượng pin	Tai nghe: 30mAh*2 Hộp sạc: 300mAh																																																																																		
Thời gian sạc	Khoảng 1.5 giờ																																																																																		
Thời gian sử dụng	Khoảng 5-7 giờ																																																																																		
Màng loa	φ13mm																																																																																		
Trọng lượng tai nghe	3.4g*2																																																																																		
Trọng lượng hộp sạc	23.4g																																																																																		
Thiết bị	Trạng thái	Đèn báo																																																																																	
Tai nghe (Đèn trắng và xanh)	Đang sạc	Đèn trắng sáng ổn định																																																																																	
	Sạc đầy	Đèn trắng chuyển sang màu xanh và tắt sau 30 giây																																																																																	
	Chế độ ghép nối	Tai chính: Đèn trắng và đèn xanh nhấp nháy luân phiên Tai phụ: Đèn xanh nhấp nháy 5 giây mỗi lần																																																																																	
	Kết nối thành công	Đèn tắt																																																																																	
Hộp sạc (Đèn trắng và xanh)	Đang sạc	Đèn trắng sáng nhấp nháy																																																																																	
	Sạc đầy	Đèn trắng sáng ổn định																																																																																	
	Pin yếu	Đèn xanh nhấp nháy chậm																																																																																	
Cài đặt gốc	Khi tai nghe ngắt kết nối với thiết bị, trạng thái bật nguồn	Đèn trắng và xanh sáng cùng lúc sau đó đèn trắng nhấp nháy 1 giây để tắt nguồn																																																																																	
Chức năng	Tai nghe bên trái	Tai nghe bên phải																																																																																	
Chơi/dừng nhạc Trả lời cuộc gọi	Chạm 1 lần	Chạm 1 lần																																																																																	
Bài hát tiếp theo		Chạm 2 lần																																																																																	
Bài hát trước đó	Chạm 2 lần																																																																																		
Tăng âm lượng		Chạm và giữ 2 giây																																																																																	
Giảm âm lượng	Chạm và giữ 2 giây																																																																																		
Chế độ chơi game	Chạm 3 lần																																																																																		
Kết thúc cuộc gọi	Chạm 2 lần	Chạm 2 lần																																																																																	
Từ chối cuộc gọi	Chạm và giữ 2 giây	Chạm và giữ 2 giây																																																																																	
Trợ lý ảo		Chạm 3 lần																																																																																	
Cài đặt gốc	Ngắt kết nối với mọi thiết bị, chạm 5 lần																																																																																		