







尺寸: 60mm*90mm

BLUETOOTH SPEAKER Rezo Light K238 User Manual  Thank you for purchasing Bluetooth Speaker Rezo Light K238. Please carefully read user guide in properly and keep this for further reference.	Packing list  1 pc speaker 1 pc user manual 1 pc Type C charging cable Key function direction 	Key function direction 1. Mode switch: Long press to change LED mode, short press to switch function (Bluetooth/FM/TF) 2. Power/Play switch: long press to turn on/off, short press: play / pause; when calling, short press for answer or hang up the phone,click twice for reject the calling; click twice to call the latest incoming / outgoing call. 3. TYPE C charging Port. If there is a warning sound when playing, it is power low, please charge the speaker. (Charging voltage: 5V) 4. TF card port, support MAX 32G flash, Compatible with MP3 in FAT32 format. 5. Short press to volume up, long press to change into next song. Click twice for TWS function or disconnect bluetooth 6. Short press to volume down, long press to change into last song. Click twice for TWS function or disconnect bluetooth Bluetooth Connection 1. Start the speaker, there is a prompt tone, Bluetooth enters the pairing mode. 2. Turn on Bluetooth in your device, search for the Bluetooth code name "Rezo Light K238" and click; after a few seconds, you will hear the prompt tone of successful pairing and connection, the mobile phone displays connected. 3. In subsequent use, as long as the device's bluetooth is turned on, it can be automatically connected. 4. Click twice button "+" or "-" to disconnect Bluetooth. TWS function While at the same time open two devices and donot connect in the bluetooth mode, double click button "+" or "-" either of the speaker and then, you will hear the prompt tone of successful pairing and connection. You search for the Bluetooth and click to use this function.	Radio function Turn on the speaker, short press the mode button to select Radio mode. Press the power/play button to search and save channel automatically for your first use. After save completely, press "+" or "-" to select previous or next channel. Attentions 1. Do not use abrasive cleaners to clean this product. 2. Do not allow this product to be heated, close to fire source or direct sunlight for a long time. It will easy to burn and damage the electronic components. 3. Do not attempt to disassemble this product to make any modifications. 4. Do not use this product in the rain. 5. If you do not plan to use this product for a long time, please store it in a dry environment and charge the speaker at least once a month to prolong its life and avoid extreme temperatures and dust. 6. If you saw smoke coming out of the machine or other improper phenomenon , please contact the retailer to solve the issue immediately. 7. Do not throw the machine. Note! In order to improve product performance, our products are constantly updated. It is no additional notice about technical issues and this manual is for reference only, please forgive. Thank you for your purchase.
--	--	---	--

尺寸: 60mm*90mm

LOA BLUETOOTH Rezo Light K238 Hướng dẫn sử dụng  Cảm ơn bạn đã lựa chọn Loa Bluetooth Rezo Light K238. Vui lòng đọc kỹ hướng dẫn để sử dụng đúng cách và giữ lại để tham khảo thêm.	Bộ sản phẩm gồm  1 loa bluetooth 1 hướng dẫn sử dụng 1 dây sạc loa Type C Chức năng các phím 	Chức năng các phím 1. Công tắc chế độ: Nhấn và giữ để thay đổi chế độ đèn LED, nhấn nhanh để chuyển chức năng (Bluetooth/FM/TF) 2. Công tắc Nguồn/Phát: nhấn và giữ để bật/tắt, nhấn nhanh: phát/tạm dừng; khi có cuộc gọi đến, nhấn nhanh để trả lời hoặc cúp máy, nhấp đúp để từ chối cuộc gọi; nhấp đúp để gọi cuộc gọi đến/di gần nhất. 3. Cổng sạc TYPE C. Nếu có âm thanh cảnh báo khi phát, thì nguồn pin đang yếu, vui lòng sạc loa. (Điện áp sạc: 5V) 4. Cổng thẻ TF, hỗ trợ MAX 32G, Tương thích với MP3 ở định dạng FAT32. 5. Nhấn nhanh để tăng âm lượng, nhấn và giữ để chuyển sang bài hát tiếp theo. Nhấp đúp để bật chức năng TWS hoặc ngắt kết nối bluetooth 6. Nhấn nhanh để giảm âm lượng, nhấn và giữ để chuyển sang bài hát cuối cùng. Nhấp đúp để bật chức năng TWS hoặc ngắt kết nối bluetooth Kết nối Bluetooth 1. Khởi động loa, có âm báo nhắc, Bluetooth chuyển sang chế độ chờ ghép nối. 2. Bật điện thoại di động, bật Bluetooth, tìm kiếm tên Bluetooth "Rezo Light K238" và nhấp vào; sau vài giây, bạn sẽ nghe thấy âm báo nhắc ghép nối và kết nối thành công, điện thoại di động hiển thị được kết nối. 3. Trong lần sử dụng tiếp theo, Loa có thể tự động kết nối khi Bluetooth của thiết bị mà được kết nối gần nhất đang mở. 4. Nhấn đồng thời nút "+" hoặc "-" để ngắt kết nối Bluetooth. Kết nối hai loa Mở nguồn hai loa cùng một thời gian và ở trạng thái không kết nối bluetooth, nhấn 2 lần nút "+" hoặc "-" của 1 trong 2 loa để có thể kết nối hai loa với nhau. Bạn sẽ nghe tiếng báo hiệu cho sự kết nối thành công và sau đó tìm ở thiết bị kết nối Bluetooth và nhấn vào để sử dụng chức năng này.	Chức năng radio Bật loa, nhấn nhanh nút đèn để chọn chế độ Radio. Nhấn nút nguồn/phát để tự động tìm kiếm và lưu kênh cho lần sử dụng đầu tiên. Sau khi lưu hoàn toàn, nhấn + và - để chọn kênh trước và tiếp theo. Chú ý 1. Không sử dụng chất tẩy rửa mài mòn để làm sạch sản phẩm. 2. Không để Loa bị làm nóng, gần nguồn lửa hoặc tiếp xúc trực tiếp với ánh nắng mặt trời trong thời gian dài, nó sẽ dễ làm chảy và hỏng các linh kiện điện tử. 3. Không cố gắng tháo rời sản phẩm này để thực hiện bất kỳ sửa chữa nào. 4. Không sử dụng sản phẩm này dưới trời mưa. 5. Nếu bạn không định sử dụng sản phẩm này trong một thời gian dài, vui lòng bảo quản nó ở nơi khô ráo và sạc loa ít nhất một tháng một lần để kéo dài tuổi thọ của loa cũng như tránh nhiệt độ quá cao và bụi. 6. Nếu nhìn thấy khói bốc ra từ máy hoặc hiện tượng bất thường khác vui lòng liên hệ với nhà bán lẻ để giải quyết vấn đề ngay lập tức. 7. Không tác động mạnh hay để vật nặng lên loa. Ghi chú! Để nâng cao hiệu suất của sản phẩm, sản phẩm của chúng tôi được cập nhật liên tục. Nội dung có thể thay đổi mà không báo trước và sách hướng dẫn này chỉ mang tính chất tham khảo, mong bạn thứ lỗi. Cảm ơn bạn vì đã mua hàng.
---	--	--	--