HƯỚNG DẪN SỬ DỤNG

TAI NGHE BLUETOOTH TWS T206

Sạc đầy tai nghe trước khi sử dụng.

Mẹo: Giữ tai nghe cách xa thẻ tín dụng hoặc phương tiện lưu trữ từ tính khác; tránh trường hợp thông tin được lưu trữ có thể bị mất do quá trình khử từ.

Cách kết nối với tai nghe Bluetooth (Lưu ý: Ví dụ sau áp dụng khi dùng iPhone)

Để thuận tiện cho khách hàng, bên trái và phải của hai tai nghe Bluetooth đã được ghép nối và kết nối với nhau trước khi xuất xưởng.

Tổng quan
1.Tai nghe
2.Cảm ứng đa chức năng
3.Điểm sạc tai nghe
4.Loa
5.Micro
6.Hộp sạc
7.Cổng sạc
8.Đèn LED



Vị trí tai nghe
Để đặt tai nghe một cách chính xác, hãy xoay và điều chỉnh để tránh tai nghe bị rơi ra.

● Chế độ tai nghe kép - Lần đầu sử dụng tai nghe

1. Đối với lần sử dụng đầu tiên, sau khi sạc với hộp sạc, đèn LED của hộp sạc hiển thị màu trắng; đặt tai nghe bên trái (L) và phải (R) vào hộp sạc để kích hoạt.

2. Tháo tai nghe bên trái (L) và phải (R) khỏi hộp sạc. Tai nghe bên trái (L) và phải (R) sẽ ghép nối tự động và có âm báo nhanh khi hoàn thành ghép nối TWS.

3. Khởi động Bluetooth trên điện thoại và tìm kiếm T206. Sau khi tìm thấy T206, nhấp vào ghép nối để hoàn tất kết nối.

● Chế độ một tai nghe (Sử dụng độc lập cho 1 trong 2 bên tai nghe)
1. Khi tai nghe được tháo khỏi hộp sạc, tai nghe sẽ tự động được bật, đèn báo hiển thị màu trắng nhấp nháy sẵn sàng trong trạng thái ghép nối.
2. Khởi động Bluetooth trên điện thoại và tìm kiếmT206.
3.Sau khi tìm thấy T206, bấm ghép nối để hoàn tất kết nối.

Hoạt động cơ bản
Tự động bật/ tắt nguồn: Khi bạn mở nắp hộp sạc, tai nghe sẽ tự động được bật và kết nối TWS được thiết lập thành công, tai nghe sẽ tự động tắt nếu việc ghép đôi không hoàn thành sau 3 phút. Khi tai nghe được đặt vào hộp sạc và đóng nắp hộp sạc, tai nghe sẽ tự động tắt và đi vào trạng thái sạc.

Ghép nối thủ công TWS: Khi tai nghe bên trái và bên phải bật nguồn và trong trạng thái ghép nối, chạm liên tiếp hai lần vào tai nghe để bắt đầu ghép nối TWS, kèm theo đèn báo màu trắng nhấp nháy. Sau khi kết nối thành công, đèn màu trắng nhấp nháy nhanh.

Kết nối: sau khi tai nghe bên trái và bên phải hoàn tất ghép nối, khi bạn mở nắp hộp sạc, đèn báo màu trắng nhấp nháy nhanh, bây

giờ hãy tìm kiếm T206. Nhấn vào kết nối, khi kết nối thành công, sẽ nghe âm báo. Trong trường hợp 2 tai nghe đã bị xóa kết nối, chỉ có 1 tai nghe được sử dụng.

Trả lời cuộc gọi: Khi có cuộc gọi đến, chạm liên tiếp hai lần vào tai nghe bên trái (L) hoặc tai nghe phải (R) để trả lời cuộc gọi.

Kết thúc cuộc gọi: Trong khi gọi, chạm liên tiếp hai lần vào tai nghe bên trái (L) hoặc tai nghe phải (R) để kết thúc cuộc.

Hủy cuộc gọi: Sau khi quay số cuộc gọi, chạm hai lần liên tiếp vào tai nghe bên trái (L) hoặc tai nghe phải (R) để hủy cuộc gọi.

Phát hoặc tạm dừng nhạc: Khi nhạc đang được phát, chạm hai lần liên tiếp vào tai nghe bên trái (L) hoặc tai nghe phải (R) để tạm

dừng nhạc hoặc lặp lại thao tác tương tự để phát lại nhạc.

Bài hát trước: Chạm và giữ MFB bên trái (L) trong khoảng 3 giây.

Bài hát tiếp theo: chạm và giữ MFB bên phải (R) trong khoảng 3 giây.

Chế độ game: Chạm liên tục 3 lần vào MFB để bật "Chế độ độ trễ thấp", kèm âm báo 2 tiếng beep sau khi kích hoạt, lặp lại thao tác để tắt chế độ độ trễ thấp, kèm âm báo 3 tiếng beep khi tắt kích hoạt.

Kết nối lại tự động: Sau khi tai nghe được bật, chúng được kết nối lại với các thiết bị được ghép nối cuối cùng.

Hiển thị mức pin của iOS: Sau khi tai nghe được kết nối với iOS, có thể xem được mức pin của tai nghe.

Cảnh báo pin yếu: tín hiệu báo 5 phút một lần, đèn LED màu trắng sáng nhấp nháy cứ sau 10 giây cho đến khi tai nghe tắt nguồn.

Bộ sạc và pin
Trước khi sử dụng bất kỳ bộ sạc nào để sạc tai nghe, hãy kiểm tra xem các thông số kỹ thuật của bộ sạc có đáp ứng yêu cầu hay không. Điện áp đầu ra được đề nghị của bộ sạc là DC5V +/- 0.25V và dòng điện đầu ra được đề nghị là 500 mA. Điện áp sạc quá cao có thể làm hỏng tai nghe.

Cảnh báo: Khuyến cáo nên dùng bộ sạc theo đúng tiêu chuẩn

được đề nghị. Việc sử dụng các loại bộ sạc khác có thể dẫn đến nguy hiểm.

Sạc pin
Tai nghe sử dụng pin sạc không thể tháo rời. Không tìm cách tháo pin ra khỏi tai nghe hoặc hộp sạc; nếu không, tai nghe có thể bị hỏng. Nếu tai nghe không được sử dụng trong một thời gian dài, hãy giữ nó ở nơi mát mẻ và thông thoáng, và sạc tai nghe hai tháng một lần.

1. Đèn LED nhấp nháy màu trắng sau khi tai nghe được kết nối, hãy đặt tai nghe vào hộp sạc. Nếu không, tai nghe sẽ tự động tắt nguồn.

2.Nếu cả tai nghe và hộp sạc đều hết pin, đặt tai nghe vào hộp

sạc, cắm sạc hộp sạc qua cổng USB-Type C. Hộp sạc và tai nghe sẽ được sạc đồng thời.

3. Tai nghe được sạc qua hai điểm tiếp xúc kim loại trong hộp sạc và đèn báo cố định màu trắng trong khi sạc. Sạc đầy mất khoảng hai giờ. Đèn báo sẽ tắt khi tai nghe được sạc đầy. Sau đó, có thể lấy tai nghe ra để sử dụng. Đèn LED hiển thị màu trắng nhấp nháy khi hộp sạc đang được sạc . Sạc đầy mất khoảng hai giờ. Đèn LED hiển thị màu trắng sẽ tắt khi hộp sạc được sạc đầy.

4. Tai nghe khi sạc đầy có thể cung cấp khoảng 4 giờ đàm thoại, 6 giờ nghe nhạc hoặc 95 giờ trong thời gian chờ. Thời gian nói chuyện thực tế và thời gian chờ có thể khác nhau tùy theo điện thoại di động, cài đặt, phương thức sử dụng và môi trường.

USER MANUAL

TRUE WIRELESS T206

Fully charge the earphone before using.

Tip: Keep the earphone away from your credit card or other magnetic storage media; otherwise, the stored information may be lost due to demagnetization.

How to connect with the Bluetooth earphone (Note: Use iPhone for example)

For customer's convenience of operation, the left- and right-channel stereo of the two Bluetooth earphones has been paired and connected before leaving factory.

Overview
1.Earbuds
2.Touch Multi-function Button(MFB)
3.Charging Contacts
4.Speaker
5.Microphone
6.Charging box
7.Charging Connector
8.Indicator Light



Earbud Placement
To place the earbuds correctly, rotate and adjust to prevent the earbuds from falling off.

●Dual-earphone mode – Initial use of the earphone

1. For the first use, after charging with the charging box, the white LED of the charging box is on; place the left (L) and right (R) headphones in the charging box for activation.

2. Remove the left (L) and right (R) earbud from the charging box. The left (L) and right (R) earbud implement TWS pairing automatically, and have a electronic tone when completing the TWS pairing.

3. Start the Bluetooth on your phone, and search for T206. After T206 is found, click Pair to complete connection.

●Single-earphone mode (Using any of the earbud independently)
1.when the earbud is removed from the charging base, the headset is automatically turned on and the white indicator blink.
2. Start the Bluetooth on your phone, and search for T206.
3.After T206 is found, click Pair to complete connection.

Basic Operations
Auto power-on/off: When you open the cover of the charging box, the earbud is automatically powered on and the TWS connection is successfully established, the earbud automatically shut down after 3 minutes of pairing timeout. When the earbud is put into the charging box and close cover of charging box, the earbud is automatically powered off and enters the charging state.

Manual TWS pairing: When the left and right earbuds power on and enter the pairing state, continuous touch twice on R & L earbuds to enter TWS pairing, and the white indicator blinks twice in every second. After the successful paring, the white indicator become quick blinks.

Connection: after the left and right earbuds completed pairing, when you open the cover of the charging box, the white indicator blinks quickly, now search for T206. Click Connect, Successfully connected with a electronic tone. If the pairing record has been cleared, the earbud must enter the TWS pairing mode again; otherwise, only one earbud can be used.

Answer a call: When there is an incoming call, continuous touch twice the left (L) or right (R) MFB to answer the call.

End a call: During a call, continuous touch twice the left (L) or right (R) MFB to end the call.

Cancel a call: After you dial a call, continuous touch twice the left (L) or right (R) MFB to cancel the call.

Play or pause music: When the music is playing, continuous touch twice the left (L) or right (R) MFB to pause the music, repeat the step to restart playing the music again.

Last song: Touch and hold the left (L) MFB for 3 seconds.

Next song: touch and hold the right (R) MFB for 3 seconds.

Game mode: Continuous touch 3 times on the earbud MFB to turn on the "low-latency mode", this process will be accompanied by 2-beep tone when activating, repeat the operation to turn off low latency mode which will be accompanied by a 3-beep tone when deactivating.

Automatic re-connection: After the earbud are powered on, they

are actively re-connected to the last paired device.

iOS battery level display: After the earbud is connected to the iOS phone, the battery level of the earbud can display in phone.

Low-power alarm: in low power status, alarm every 5 minutes, white LED blink every 10 seconds until the earbud power off.

Charger and Battery
Before using any charger to charge this earphone, check whether the specifications of the charger meet requirements. The recommended output voltage of the charger is DC5V+/-0.25V, and the recommended output current is 500 mA. An over-high charging voltage may damage the earphone.

Warning: Use the recommended charger whenever possible. Use of other types of chargers may violate the warranty terms of the equipment and results in danger. If the charging cable is delivered with the earphone, connect the cable to a CCC-certified charger or computer to charge the earphone.

Charging the Battery
The earphone use embedded charging battery that cannot be removed. Do not attempt to remove the battery from the earphone or the charging box; otherwise, the earphone may be damaged. If the earphone is not used in a long time, keep it in a cool and well-ventilated place, and charge the earphone once every two months.

1.When the LED indicator flash white after connected earbuds, put the earphone into the charging box. Otherwise the earphone will power off automatically.

2.If both the earbuds and charging box are out of power, insert the charging cable into the USB-Type C port on the charging box, and plug the charger into the AC socket. The charging box and earphone will be charged simultaneously.

3. The earbud is charged through two metal contacts during charging in the box, and the white indicator light on while charging. The full charge takes about two hours. The indicator goes off when the earphone is fully charged. Then you can take out your earbud for use. When the charging box is being charged, the white indica

tor lights on. The full charge takes about two hours. The white indicator lights off when the charging box is fully charged. Then you can disconnect the charger from the socket and charging box.

4. A fully charged battery of earphone can provide about 4 hours of talk time, 6 hours of music time, or 95 hours of standby time. The actual talk time and standby time may vary with cell phones, settings, use methods, and environment.

105双铜 单色印刷 装订90x60mm