


Instruction


A. Features

1. Display Hour, Minute, Second, Month, Day and Week
2. Daily alarm
3. 12/24H format, Auto Calendar
4. 1/100 second Chronograph with split functions
5. EL backlight



B. Operational Manual

Press B Key convert the mode:



At any state, press A key EL backlight for 3s.

In normal model, Press D key to display Date and Month; Press C key to display Alarm time

Chronograph function

- ◆ In normal display mode: press B key once, enter Chronograph mode
- ◆ Press D key once to start running: When running, if press D key again will stop running, if press C key, will stop display running, but run at back. Press D key again, will running again. Press C key to zero.

Alarm Setting

- ◆ In normal display Mode, press B key twice enter into Alarm mode and Hours flashing.
- ◆ Press D key the adjust the Alarm Hours..
- ◆ Press C key the Minutes will flash , press D key to adjust the Alarm Minutes.
- ◆ Press B key to exit.

Alarm ON/OFF

- ◆ In normal model hold C key and D key together to ON/OFF the Alarm function.

Time & Date Setting

- ◆ In normal display Mode, press B key three times to enter time & date setting mode and the seconds will flashing. Press D key to zero.
- ◆ Press C key the Minutes will flash. Press D key to adjust the correct Minutes.
- ◆ Press C key the Hours will flash. Press D key to adjust the correct Hours. (Pay attention to AM/PM, if show that icon means 12H format, otherwise means 24H format)
- ◆ Press C key the Date will flash. Press D key to adjust the correct Date.
- ◆ Press C key the Month will flash. Press D key to adjust the correct Month.
- ◆ Press C key the Week will flash. Press D key to adjust the correct Week.
- ◆ Press B key to exit.