

User's Guide 5338

ENGLISH

Congratulations upon your selection of this CASIO watch.

Important!

- This manual provides a brief overview of your watch.

E-1

For a full Operation Guide and Q&A information about this product, go to the website below.
<http://world.casio.com/manual/wat/>




Configuring Home City, Time and Date Settings

- Configure Home City and summer time settings first. After that, configure time and date settings.
1. In the Timekeeping Mode, hold down (A) for about two seconds until the seconds start to flash. This is the setting mode.

E-2

2. Press (C) to move the flashing in the sequence shown below to select a setting.



E-3

3. Use (B) and (D) to change the selected setting.

Screen	This setting item:	Operation
36	Reset the seconds to 00	Press (D).
OFF	Toggle between Daylight Saving Time (ON) and Standard Time (OFF)	Press (D).
TYO	Change the city code	Use (D) (East) and (B) (West).
P 10:00	Change the hour or minute	Use (D) (+) and (B) (-).
12H	Toggle between 12-hour (12H) and 24-hour (24H) timekeeping	Press (D).
6:30 20 14	Change the year, month, or day	Use (D) (+) and (B) (-).


4. Press (A) to exit the setting screen.

E-4

E-5

Mode Selection and Operations

- Press (C) to change the mode.



E-6

E-7

Adjusting the Analog Hand Setting

Use the operations below to adjust the analog hands so their settings match the digital time.



- (D) (three seconds in Timekeeping Mode): Enters analog hand setting mode.
- (D): Advances minute hand 20 seconds.
- (B): (while holding down (D)): Locks high-speed hand movement.
- (A): Exits analog hand setting mode.

E-8

Specifications

- Accuracy at normal temperature:** ±30 seconds a month
- Digital Timekeeping:** Hour, minutes, seconds, p.m. (P), month, day, day of the week
- Time format: 12-hour and 24-hour
- Calendar system: Full Auto-calendar pre-programmed from the year 2000 to 2099
- Other: Home City code (can be assigned one of 48 city codes); Standard Time/Daylight Saving Time (summer time)
- Analog Timekeeping:** Hour, minutes (hand moves every 20 seconds)
- World Time:** 48 cities (29 time zones)
- Other: Daylight Saving Time/Standard Time
- Alarms:** 5 daily alarms (with 1 snooze alarm); Hourly time signal
- Stopwatch:**
 - Measuring unit: 1/100 second
 - Measuring capacity: 23:59'59.99"
 - Measuring modes: Elapsed time, split time, two finishes

E-9

Countdown Timer:

Measuring unit: 1 second
 Countdown range: 24 hours
 Countdown start time setting range: 1 minute to 24 hours (1-minute increments)

Illumination: LED (light-emitting diode)

Power Supply: Two silver oxide batteries (Type: SR726W)

Approximately 2 years on type SR726W (assuming alarm operation 20 seconds per day and one illumination operation 1.5 seconds per day)

Frequent use of illumination runs down the battery.

Specifications are subject to change without notice.



City Code Table



E-10

L-1

City Code Table

City Code	City	UTC Offset/ GMT Differential
PPG	Pago Pago	-11
HNL	Honolulu	-10
ANC	Anchorage	-9
YVR	Vancouver	-8
LAX	Los Angeles	-8
YEA	Edmonton	-7
DEN	Denver	-7
MEX	Mexico City	-6
CHI	Chicago	-6
MIA	Miami	-5
YTO	Toronto	-5
NYC	New York	-5
SCL	Santiago	-4
YHZ	Halifax	-4
YYT	St. John's	-3.5

City Code	City	UTC Offset/ GMT Differential
RIO	Rio De Janeiro	-3
RAI	Praia	-1
UTC		
LIS	Lisbon	0
LON	London	0
MAD	Madrid	0
PAR	Paris	0
ROM	Rome	0
BER	Berlin	0
STO	Stockholm	0
ATH	Athens	0
CAI	Cairo	0
JRS	Jerusalem	0
MOW	Moscow	0
JED	Jeddah	0

City Code	City	UTC Offset/ GMT Differential
THR	Tehran	+3.5
DXB	Dubai	+4
KBL	Kabul	+4.5
KHI	Karachi	+5
DEL	Delhi	+5.5
DAC	Dhaka	+6
RGN	Yangon	+6.5
BKK	Bangkok	+7
SIN	Singapore	+7
HKG	Hong Kong	+8
BJS	Beijing	+8
TPE	Taipei	+8
SEL	Seoul	+9
TYO	Tokyo	+9
ADL	Adelaide	+9.5

City Code	City	UTC Offset/ GMT Differential
GUM	Guam	+10
SYD	Sydney	+11
NOU	Noumea	+11
WLG	Wellington	+12

- This table shows the city codes of this watch (As of December 2012).
- The rules governing global times (UTC offset and GMT differential) and summer time are determined by each individual country.

L-2

L-3